

Isotemp General Purpose and Flammable Materials Storage Refrigeration

Catalog No.
GP Freezer Model 148, 148HK

Table of Contents

Safety Information	3
--------------------------	---

Alert Signals	3
---------------------	---

Unpacking	4
-----------------	---

Visible Loss or Damage	4
------------------------------	---

Concealed Loss or Damage	4
--------------------------------	---

Performance Characteristics	5
-----------------------------------	---

Temperature Stability	5
-----------------------------	---

Electrical Requirements	5
-------------------------------	---

Safety Information

Alert Signals

Your satisfaction and safety are important to Fisher

Scientific and complete understanding of this unit is

Unpacking

Save all packing material if apparatus is received damaged. This merchandise was carefully packed and thoroughly inspected before leaving our factory.

Responsibility for its safe delivery was assumed by the carrier upon acceptance of the shipment; therefore, claims for loss or damage sustained in transit must be made upon the carrier by the recipient as follows:

Performance Characteristics

Temperature Ranges

151: 3° to 13°C (37° to 55°F)

152: 3° to 13°C (37° to 55°F)

148: -20° to -10°C (-4° to 14°F)

149: -20° to -10°C (-4° to 14°F)

Temperature Stability

@ 4 °C ±4 °C

@ -20 °C ±4 °C

Electrical Requirements

Models 148, 149, 152:

115 Volts ±10%, 60 Hz, 3.5 Amps

Models 148HK, 149HK, 152HK:

220 Volts +/-10%, 50Hz, 3.5 Amps

Installation

Selecting a Location

Choose a location for the refrigerator that will provide at least four inches of clearance between the cabinet and any adjacent vertical surface at the sides and four inches

at the top. Twelve inches of clearance is required above the top surface of the refrigerated cabinet. Appropriate

electrical power must be available. Locate the refrigerator within eight feet of the power outlet so that no extension cord is required.

Leveling the Unit



Warning

For personal safety this unit must be properly grounded.



Caution

unit running, check that the line voltage is within $\pm 10\%$ of that specified on the data plate.

The power cord of this instrument is equipped with a three prong (grounding) plug (NEMA 5-15P). This plug mates with a standard three prong (grounding) wall receptacle (NEMA 5-15R) to minimize the potential of an electrical shock hazard. The customer should have the wall receptacle and circuit checked by a qualified electrician to verify the receptacle is properly grounded and is connected to a minimum 15 amp service.

WARNING: DO NOT under any circumstances cut or remove the third (ground) prong from the power cord. DO

Aluminum Alloys are susceptible to corrosion when exposed to but not limited to most inorganic acids, bases and salts with a pH outside of their passive range of pH 4 to 9. It is also important to recognize that the compatibility

ty of aluminum alloys with mixtures of organic compounds cannot always be predicted from their compatibility with

Troubleshooting

This table is intended to assist in resolving user-correctable Refrigerator problems by relating symptoms to their likely causes. If service beyond the scope of this table is required, contact your nearest Fisher Scientific Service Office.

<u>Symptom</u>	<u>Probable Cause</u>	<u>Action</u>
Does Not Run	Unit Unplugged	Plug in Unit
	Blown fuse or tripped circuit breaker	Check fuse or circuit breaker at breaker box
Runs Continuously	Frost buildup on refrigeration coils	Defrost unit
Clicking Sound	The compressor is equipped with a thermal protector.	Unplug unit for 1 hr. Plug in and try running again. If the unit doesn't
	compressor when it becomes too hot. A clicking sound occurring about every 30 seconds indicates this protector is working	
Insufficient Cooling	Thermostat set too high	Reduce thermostat setting
	Unit frosted	Defrost unit

Maintenance



Warning

Cabinet Cleaning

The cabinet interior should be cleaned frequently. Any

Warranty

Laboratory instruments and equipment manufactured by Fisher Scientific Company L.L.C. – Laboratory Equipment Division (hereinafter called “the Company”) are warranted only as stated below.

Subject to the exceptions and under the conditions specified below, the Company agrees, at its election, to

correct by repair, by replacement, or by credit to the purchaser, any defect of materials or workmanship which